

Upgrade instruction for gb20181019NSX

This firmware can be applied to all cameras which got FW with ending NSX.

Explicitly following models:

EBC-3139, EBC-3140, EBC-3141

EFD-3131, EFD-3245, EFD-3255, EFD-3247, EFD-3257, EFD-3248, EFD-3258, EFD-3261, EFD-3266

EWPC-3210, EWPC-3220, EWPC-3212, EWPC-3222, EWPC-3213, EWPC-3223, EWPC-3270, EWPC-3271

1. Enter the IP address of camera into the Internet Explorer
2. Go to System -> Software upgrade
3. At "Step1" search and select the ulmage_userland* file
4. At "Step2" select "ulmage+userland.img".
5. At "Step3" push "Save".

The screenshot shows the GEUTEBRÜCK web interface. The top navigation bar includes links for Home, System, Streaming, Camera, and Logout, along with a user identifier 'EFD-3255'. A left sidebar contains a menu with items like System, Security, Network, DDNS, Mail, FTP, HTTP, Events, Storage management, Recording, Schedule, File location, and View information. The main content area is titled 'Upgrade' and contains the following steps:

- Step1:** Upload the binary file. A button labeled 'Datei auswählen' is followed by the text 'ulmage_userland_gb2.....NSX'.
- Step2:** Select binary file you want to upgrade. A dropdown menu shows 'uImage_userland'.
- Step3:** Click the upgrade button to start the upgrade process. An 'Upgrade' button is visible at the bottom.

6. Wait until the camera has uploaded the Firmware to 100% and webpage has been reloaded and shown again.

7. Reload the Webpage once again with F5 or Reload button of web browser.

NOTE: In very few cases functions and/or web menu surfaces can be disturbed. If so, you should execute a "Partial Restore". Please be aware, that after partial restoring all parameters (without network parameters) will get its default values!